FREESTYLE FREESTYLE ROCKER FROM SQUEAKING

HOW TO STOP YOUR



If your Freestyle Rocker has begun to squeak, try one of these three methods and you'll be rocking squeak-free in no time:

You hear a clicking sound: METHOD I	You hear squeaking: METHOD 2	You hear squeaking: METHOD 3
Tighten these bolts.	Using silicone lubricant spray, spray around the top of the shock.	Using WD-40, spray a small amount on both sides of the frame, where the shock meets the lower foot.

TIP: You can typically find silicone lubricant spray at hardware or home improvement stores.

